

# Big Doors


## MultiGlide™ - Traditional Clad - Pocket Door No Screen/Screen/Multi Screen




### 4 11/16" Bottom Rail On-Floor Drainage Sill Elevations

(When changing rough opening width - adjust each panel and the pocket by the same amount.)


R.O. including Pocket  
R.O. 2'-8 3/8" (822)  
to 5'-4 5/8" (1635)












R.O. including Pocket  
R.O. 4'-8 1/8" (1426)  
to 10'-0" (3048)



R.O. including Pocket  
R.O. 6'-7 3/4" (2026)  
to 14'-7 5/8" (4461)



R.O. including Pocket  
R.O. 8'-7 3/8" (2626)  
to 19'-3 1/4" (5874)



### Notes:

Dimensions in parentheses are in millimeters.

Overall sizes can be adjusted in 1/8" (3) increments.


# Big Doors

## MultiGlide™ - Traditional Clad - Pocket Door No Screen/Screen/Multi Screen



### 4 11/16" Bottom Rail Flush Sill Elevations

(When changing rough opening width - adjust each panel and the pocket by the same amount.)



### Notes:

Dimensions in parentheses are in millimeters.

Overall sizes can be adjusted in 1/8" (3) increments.

Date: 07/22/19  
Scale: 1/8" (3) = 1' (305)


# Big Doors

## MultiGlide™ - Traditional Clad - Pocket Door No Screen/Screen/Multi Screen



### 8" Bottom Rail On-Floor Drainage Sill Elevations

(When changing rough opening width - adjust each panel and the pocket by the same amount.)



#### Notes:

Dimensions in parentheses are in millimeters.  
Overall sizes can be adjusted in 1/8" (3) increments.


# Big Doors

MultiGlide™ - Traditional Clad - Pocket Door  
No Screen/Screen/Multi Screen



## 8" Bottom Rail Flush Sill Elevations

(When changing rough opening width - adjust each panel and the pocket by the same amount.)



### Notes:

Dimensions in parentheses are in millimeters.  
Overall sizes can be adjusted in 1/8" (3) increments.

# Big Doors

## MultiGlide™ - Traditional Clad - Pocket Door No Screen/Screen/Multi Screen




### 12" Bottom Rail

### On-Floor Drainage Sill Elevations


(When changing rough opening width - adjust each panel and the pocket by the same amount.)

R.O. including Pocket  
R.O. 2'-8 3/8" (822)  
to 5'-4 5/8" (1635)




1 Panel

R.O. including Pocket  
R.O. 4'-8 1/8" (1426)  
to 10'-0" (3048)




2 Panel

R.O. including Pocket  
R.O. 6'-7 3/4" (2026)  
to 14'-7 5/8" (4461)




3 Panel


R.O. including Pocket  
R.O. 8'-7 3/8" (2626)  
to 19'-3 1/4" (5874)




4 Panel




5 Panel




6 Panel




2 Panel




4 Panel




6 Panel



8 Panel



10 Panel



12 Panel

### Notes:

Dimensions in parentheses are in millimeters.

Overall sizes can be adjusted in 1/8" (3) increments.

Date: 07/22/19  
Scale: 1/8" (3) = 1' (305)


# Big Doors

## MultiGlide™ - Traditional Clad - Pocket Door No Screen/Screen/Multi Screen



### 12" Bottom Rail Flush Sill Elevations

(When changing rough opening width - adjust each panel and the pocket by the same amount.)



#### Notes:

Dimensions in parentheses are in millimeters.  
Overall sizes can be adjusted in 1/8" (3) increments.

Date: 07/22/19  
Scale: 1/8" (3) = 1' (305)